


PARTS LIST

SAFETY PRECAUTION

Parts identified by the \triangle symbol are critical for safety. Replace only with specified part numbers.

1. PACKING AND ACCESSORY ASSEMBLY <M1>

The instruction manual to be provided with this product will differ according to the destination.



MODEL	MARK
GR-FXM39EK	A
GR-FXM39EX	B
GR-FXM39EY	C
GR-FXM39EZ	D
GR-FXM393EX	E
GR-FXM393EY	F
GR-FXM393EZ	G

PACKING AND ACCESSORY ASSEMBLY <M1>

\triangle Symbol No.	Part No.	Part Name	Description	Local
1	LY33071-003B	PACKING CASE		
2	LY33075-001B	CUSHION		
3	LY30023-002A	POLY BAG		
4	QPA02003506P	POLY BAG	20cm x 35cm	A
4	QPA02003506	POLY BAG	20cm x 35cm	B,C,D,E,F,G
\triangle 5	LYT1061-001B	INST BOOK	(ENGLISH)	A
\triangle 5	LYT1060-002C	INST BOOK	(GERMAN)	B,C,E,F
\triangle 5	LYT1060-003C	INST BOOK	(FRENCH)	B,E
\triangle 5	LYT1060-004C	INST BOOK	(DUTCH)	B,E
\triangle 5	LYT1060-005C	INST BOOK	(SPANISH)	B,E
\triangle 5	LYT1060-006C	INST BOOK	(ITALIAN)	B,E
\triangle 5	LYT1060-007B	INST BOOK	(DANISH)	C,F
\triangle 5	LYT1060-008B	INST BOOK	(FINNISH)	C,F
\triangle 5	LYT1060-009B	INST BOOK	(SWEDISH)	C,F
\triangle 5	LYT1060-010B	INST BOOK	(NORWEGIAN)	C,F
\triangle 5	LYT1060-011B	INST BOOK	(RUSSIAN)	D,G

\triangle Symbol No.	Part No.	Part Name	Description	Local
\triangle 5	LYT1060-012B	INST BOOK	(CZECH)	D,G
\triangle 5	LYT1060-013B	INST BOOK	(POLISH)	D,G
\triangle 5	LYT1060-014B	INST BOOK	(HUNGARIAN)	D,G
6	LYT0194-001B	Q.CARD (JUK)		A
7	BT-54008-4	GUARANTY CARD		A
8	BT-54013-5	WARRANTY CARD		B,C,D,E,F,G
9	QPA02003506P	POLY BAG	20cm x 35cm	A
9	QPA02003506	POLY BAG	20cm x 35cm	B,C,D,E,F,G
\triangle 10	YQ10629E	BATTERY PACK ASSY		
11	PEMC1174	CONNECTOR		
13	LY43388-001A	LENS CAP ASSY		
\triangle 14	LY20955-001C	AC ADAPTER	AP-V13E	A
\triangle 14	LY20956-001B	AC ADAPTER	AP-V11E	
15	PEAC0362-150	A/V RCA CABLE		
\triangle 17	QMPP110-190-JR	POWER CORD(EK)	1.9m BLACK	A
\triangle 17	QMPL120-190-JR	POWER CORD(EU)	1.9m BLACK	B,C,D,E,F,G
19	LY20186-001A	SHOULDER STRAP		